

Care and Maintenance

Megasorber Acoustic Panels

Care and Maintenance



Megasorber acoustic panels require minimal care and maintenance, however from time-to-time the Soundmesh® G8 facing may require cleaning as outlined below.

Recommended cleaning product

Megasorber Clean M8, non-toxic cleaning block

Megasorber Clean M8-25: 180mm x 70mm x 25mm (thick).

Cleaning procedure

1. Dampen cleaning block with water and wring slightly, leaving the Clean M8 block damp.
2. Gently wipe the surface to remove dirt or scuff marks.
3. Rinse the Clean M8 block in water and wring slightly.
4. Wipe the Soundmesh G8 with a microfibre cloth to complete.

Do not use detergents

Megasorber Clean M8 requires only water to remove dirt or scuff marks. It cleans without the use of cleaning agents.

Important note

Megasorber Clean M8 could be abrasive on some surfaces and should only require a gentle wipe over surfaces to clean. When using on delicate surfaces, we recommend testing in an inconspicuous area first.

Note that harsh abrasion, excessive rubbing, rough handling and scuffing can cause irreversible damage to the fibres of the Soundmesh G8 fabric and should be avoided.

Do not use Megasorber AC5 to clean panels.

megasorber.com

© Copyright / CM-F01 / January 2023.

Megasorber is the registered trademark of Megasorber Pty. Ltd.

Building 3, 621 Whitehorse Road
Mitcham, Victoria, Australia 3132

E info@megasorber.com

T + 61 3 9077 2918

ACN 096 454 278 / ABN 13 096 454 278

megasorber®